




- TCM**
- The TCM detects the vehicle conditions and performs calculations and processing based on input information from each type of sensor and switch.
 - Outputs control signals to each solenoid valve so that each type of control is optimally implemented according to the vehicle conditions.



- : FRONT HARNESS
- : ENGINE HARNESS
- : ENGINE No.2 HARNESS
- : REAR HARNESS
- : REAR No.4 HARNESS
- : EMISSION HARNESS
- : DOOR HARNESS
- : INTERIOR LIGHT No.2 HARNESS